



*These instructions are for the removal and replacement of the Motor Control Assembly for a battery powered roller shade.
These instructions do not apply to a 1st generation or low-voltage roller shade.*

Step 1

Click the UP button to roll shade up to the full open position.



Step 2

Remove shade from the window brackets.



Step 3

Cut the two safety sticker tabs on the motor end label. The motor end is always located on the left side of the tube regardless of standard or reverse orientation.



Step 4

Roll the shade fabric off of the shade tube.



Step 5

Place the new motor on the table.




Step 6

Take the battery cover off the shade tube.




Step 7

Remove all the batteries out of the shade tube.



Step 8

Pull the Motor Control Assembly out of the shade tube.



Step 9

Insert the New Motor Control Assembly as shown below. Be sure the battery access slots are aligned with the slots in



Step 10

Insert the batteries into the new motor control assembly and shade tube.



Step 11

Replace the battery cover on the shade tube.



Step 12

Roll shade fabric back onto shade tube.



Step 13

Re-install the shade into the window brackets.



Step 14

Depending on which protocol you are using, follow those instructions to program shade.



Use this QR Code to view the video to these instructions.